

URSA MINI POD KIT USER MANUAL

SAFETY WARNING & INSTRUCTIONS

Please read this user manual carefully before using the product and keep the product in a safe place:

1.Warning for vulnerable consumer groups: The sale and use of e-cigarettes is prohibited for people under the age of 21. The use of e-cigarettes and liquids during pregnancy and breastfeeding, or by a non-smoker is not recommended. Keep this e-cigarette and its components out of the reach of children.

2.Battery Caution: Do not expose the device to extreme temperatures. Do not disassemble the device to service or change the battery without Lost Vape's recommendation. Contact Lost Vape or an authorized repair centre for battery servicing. Only dispose of Lithium Polymer batteries at a suitable waste disposal facility.

3. E-liquid Use: To use this product, e-liquid must be filled into the tank/pod—as explained below. ONLY E-LIQUIDS WHICH COMPLY WITH EUROPEAN UNION LAW, AND OTHER RELEVANT LAW, SHOULD BE USED IN THIS PRODUCT. Please consult with reputable e-cigarette and e-liquid dealers for advice on what e-liquids can be used in this product.

4. Verify The Authenticity: Please verify that the product is an authentic Lost Vape product before purchasing it. Fake and shoddy products may damage your personal health. To verify the product, please refer to <https://lostvape.com/anti-counterfeit/> and follow the steps described in the New Verification System. If you have any questions, please contact us by email, phone or our website to get help.

5. Pod Cartridge Attention: Do not dry burn the pod or coil. It is essential to fully saturate the cotton when having filled or refilled an empty pod. Ursa Mini Pod Cartridge and Coils are not covered under warranty once they are opened, used, or filled with liquids.

6.Contacts: For further questions or inquiries, please contact Lost Vape by email at support@lostvape.com or visit our website: www.lostvape.com.

7.Warranty: The device is covered by a 3-month warranty from the date of purchase. Please check our Warranty Guidelines for further information. Coils and/or accidental damages are not covered by this warranty.

MAIN FEATURE

- 30W MAX OUTPUT POWER
- FULL ADJUSTABLE AIRFLOW
- SMART COIL DETECTION
- BUILT-IN 1200MAH BATTERY
- UB LITE COILS COMPATIBLE
- TYPE-C FAST CHARGING


STANDARD PACKAGE

- 1× URSA MINI POD KIT
- 1× 0.4Ω UB LITE L1 COIL
- 1× 1.0Ω UB LITE L6 COIL
- 1× TYPE-C CHARGING CABLE
- 1× USER MANUAL
- 1× WARRANTY CARD

BASIC PARAMETERS

Dimension	30.7mm × 107.2mm × 26mm
Battery	1200 mAh Built-in Lithium Battery
Power Range	5-30W
Battery Voltage	3.0V-4.2V
Screen Pixel	0.69"
Body Material	Zinc Alloy & Stainless Steel

COMPONENTS OVERVIEW




① Mouthpiece	⑥ Display Screen
② Pod	⑦ Up Button (+)
③ E-liquid Filling Plug	⑧ Down Button (-)
④ Adjustable Airflow Ring	⑨ Type-C Port
⑤ Fire Button	

BASIC OPERATION

● TURN ON/TURN OFF

Press the Fire button 5 times consistently within 2 seconds to TURN ON/TURN OFF the device. Without any operations, the screen will turn into sleep mode in 20s.




● ADJUSTMENT LOCK/UNLOCK

Press and hold the Fire button and Up(+) button at the same time to Lock and Unlock the adjustment setting. The Fire button will still work under this setting.


● PUFF TIME and PUFF COUNT RESET

Press and hold the Fire and Down (-) button for 3 seconds to reset the puff time and puff count.




● AFC ADJUSTMENT

Twist the airflow control ring to adjust the airflow according to your taste.



● CHARGING

The device has a built-in DC 5V Type-C port. Connect the Type-C cable to a power source, the battery icon will begin to animate and stop animating once fully charged (Battery Voltage ≥ 4.18V). It is allowed to vape when charging.



DEFAULT MAIN INTERFACE OPERATION



① Battery Icon



② Coil Resistance



③ Power: Press the Up (+) and Down (-) buttons to adjust the wattage to the desired value.




④ Last Vaping Time: The data will be cleared after pressing the Fire Button, and your vaping time will be recalculated. (From 0.0S to 9.9S)





⑤ Puff Count: (From 000 to 999 times)

HOW TO REPLACE COIL




Step 1.Take out the pod;

Step 2.Take out the coil directly;




Step 3.Push the new coil back into the pod in the correct direction;

Step 4.Put the pod back into the device;




▲ Attention: Make sure the pod is upside down before pulling out the coil when there is juice still left in the pod to avoid leakage of the e-liquid.

HOW TO FILL WITH E-LIQUID




Step 1.Take out the pod;

Step 2.Unplug the e-liquid refilling plug on the bottom of the pod;



Step 3.Refill pod from e-liquid filling slot;

Step 4.Seal the plug after filling;



DESCRIPTION OF WARNING

Low Battery

Output will automatically cut off and the screen will show "Low Battery". This message means battery voltage below 3.3V before use or lower than 2.8V when you are using, this will continue to display for a few seconds after attempting to fire the device.

Check Atomizer

You will be asked to "Check Atomizer" when no atomizer detected, or the atomizer resistance is higher than 5Ω.

Short circuit

When the atomizer resistance is lower than 0.2Ω, the screen displays "Short circuit" once you press the Fire button.

Too Hot

The device will shut down and display "Too Hot" once the temperature of the internal board is higher than 75°C. You can use the device again when the temperature is back to 60°C.

Over 10s

Output will automatically cut off and screen shows "Over 10s" when you vape over 10s continuously.



@lost_vape
 @lost_vape
 www.lostvape.com